



Body		KK-PP2-8627	
P.No.		KK-NAME	QTY.
B-A	QJB270.2	N/A	
BA-01	GB/T6177	Screw M 6x25 (Allen)	1
BA-02	QJB270.2.3	Cover Borad Comp	1
BA-03	QJB270.2.2-4	Chain wheel adjuster Cover	1
BA-04	LY/T1187	ChainJL9-3	1
BA-05	QJB270.2.2-6	Gear(Adjusting)	1
BA-06	GJ330.I.4	Chain Bar	1
BA-07	QJB270.2.2-3	Adjust pin	1
BA-08	QJB270.2.2-1	Fixed Block	1
BA-09	QJB270.2.2-2	Gear(Adjust Pin)	1
BA-10	GB/T70.1	Screw M6X30(ALLEN)	1
BA-11	GB/T9074.4	BOLT M5X14 (Star)	2
BA-12	QJB270.2.2-7	Connecting oil pipe	1
BA-13	YD-40-13	Protection Block	2
BA-14	QJB270.2-4	Screw SPL(Sprocket)	1
BA-15	QJB270.2-3	Washer SPL(Sprocket)	3
BA-16	QJB270.2-5	Baffle (Sprocket)	2
BA-17	QJB270.2-2	Chain wheel / Sprocket	1
BA-18	QJB270.2-1	Washer/Spacer	1
BA-19	GB/T70.1	Screw M4X 12 (Star)	2
BA-20	GB/T70.1	Screw M5X 12 (Allen)	4
BA-21	GJ330.I.I.I	Oil Pump Assy	1
BA-22	QJB270.2.2	Box cover (Gear Case)	1
BA-23	GJ330.I. I.2-1	Oil Pipe	1
BA-24	GJ330.I. I.2.I	Oil Filter	1
BA-25	GJ330.I.2.I	Oil Tank	1
BA-26	GB/T70.1	Screw M5X25(Allen)	1
BA-27	GB/T93	Washer 5 Spring	1
BA-28	GB/T276	Bearing 6001-2RS/P5	1
BA-29	GJ330.I.1-3A	Worm	1
BA-30	QJB270.2.I.I	Right pinion(Big)	1




BA-31	GB/T276	Bearing 627-Z	1
BA-32	GB/T1152	Grease Nipple / Oil Cup	1
BA-33	GJ330.I.1-1	Gear case	1
BA-34	GJ330.I.1-4	Left pinion (Small)	1
BA-35	GB/T276	Bearing 6000-2RZ/P5	2
BA-36	GB/T893.2	Stop ring 26 (Inner)	1
BA-37	GB/T894.I	Stop ring 10 (Outer)	1
BA-38	GJ330-YXG	Oil Tank Lid Assy	1
BA-39	IE32FL.6.2-2	N/A	1
BA-40	CG420.I.3.1-2	Gasket (Fuel tank Lid)	1
BA-41	IE32FL.6.2-3	N/A	1
BA-42	IE32FL.6.2-4	N/A	1
BA-43			
BA-44			


P.No.			QTY.
B-B	QJB270. 1. 1	N/A	
BB-01	QJB270. 1. 1-1	Front Pipe	1
BB-02	QJB270. 1. 1-3	Lip Block	1
BB-03	GB894. 1	Stop ring 15	1
BB-04	QJB270. 1. 1-4	Shaft Sleeve (1)	1
BB-05	QJB270. 1. 1. 2	Bearing Ass'y	1
BB-06	GB12618	Rivet 4X8	1
BB-07	QJB270. 1. 1. 1-1	Joint (Front Shaft)	1
BB-08	QJB270. 1. 1. 1-2	Rubber Plug (Front Shaft)	1
BB-09	QJB270. 1. 1. 1-3	Front Shaft	1
BB-10	QJB270. 1. 1-2	Front Shaft Bracing	1
BB-11			




P.No.			QTY.
B-C	QJB270. 1. 2	Connecting Sleeve Ass'y	
BC-01	QJB270. 1. 2. 2	N/A	1
BC-02	QJB270. 1. 2. 1	Handle(Connecting Sleeve)	1
BC-03	GB/70. 1	Screw M5X20 (Allen)	2



P.No.			QTY.
B-D	QJB270. 1. 3	N/A	
BD-01	QJB270. 1. 2. 2	N/A	1
BD-02	QJB270. 1. 1. 2	Bearing Ass'y (Back Shaft)	4
BD-03	GB12618	Rivet 4X8 (Back Shaft)	1
BD-04	QJB270. 1. 3-4	Shaft Sleeve (2)	4
BD-05	QJB270. 1. 3. 2-1	Thin Pipe	1
BD-06	QJB270. 1. 3. 1-1	Back Shaft	1
BD-07	GB845	Screw ST2. 9 X 6. 5	1
BD-08	QJB270. 1. 1. 1-1	Joint(Back Shaft)	1
BD-09	GB/70. 1	Screw M5X20(Allen)	2
BD-10	GB/70. 1	Screw M6X20(Allen)	1
BD-11	QJB270. 1. 3-2	Thick Pipe	1
BD-12	QJB270. 1. 3-1	Rubber Cover (Thick pipe)	1
BD-13	QJB270. 1. 3-3	Spring (Thick pipe)	4
BD-14		Sleeve(Back Pipe)	1
BD-15			
BD-16		1490mm	
BD-17		Screw-Sleeve(Back Pipe)	



P.No.			QTY.
B-E	CG260.2	Lever Ass'y	
BE-01	CG305F.13.2	Clamp	1
BE-02	GB/T9074.4	N/A	1
BE-03	CG305F.13-10	N/A	1
BE-04	CG305F.13-11	Spring(Tine)	1
BE-05	CG305F.13-9	Spring(Safety Lever)	1
BE-06	CG305F.13-1	Spring(Throttle Lever)	1
BE-07	CG305F.13-8	N/A	1
BE-08	CG305F.13-2	N/A	1
BE-09	CG330A-3E.2.1	Throttle cable	1
BE-10	GB/T9074.4	N/A	2
BE-11	GB/T818	N/A	1
BE-12	CG305F.13-3	N/A	1
BE-13	CG260.2.1	Stop Switch	1
BE-14	BG-328A-2	N/A	1
BE-15	GB/T9074.4	N/A	1
BE-16	CG305F.13-5	N/A	1
BE-17	CG305F.13-6	Rubber Cover(Thin Pipe)	1
BE-18	CG305F.13-4	N/A	1
BE-19	GB/T889.1	N/A	3




P.No.			QTY.
B-F	CG260.3	Holder Ass'y	
BF-01	CG260.3.1	N/A	1
BF-02	CG260.3-1	N/A	1
BF-03	GB/T70.1	N/A	1
BF-04	GB/T889.1	N/A	1




P.No.			QTY.
B-G	CG260A-CE.1		1



P.No.			QTY.
B-H	CG260A.1A	Clutch Comp.	
BH-01	CG260A.1A.1	Clutch Drum	1
BH-02	GB/T893.1	Stop Ring 35 (Inner)	1
BH-03	GB/T276	Bearing 6202-2RZ/PE	1
BH-04	GB/T894.1	Stop Ring 15(Outer)	1
BH-05	CG261.1-1	Linker	1
BH-06	CG305F.14-2	Rubber Cover(Linker)	1
BH-07	GB/70+GB93+GB97	Screw M5X12 (Allen)	1
BH-08	GB/70+GB93+GB97	Screw M5X25 (Allen)	2
BH-09	CG305F.14-4	Clamp A	1
BH-10	CG305F.14-3	Clamp B	1
BH-11	GB/70+GB93+GB97	Screw M6X20 (Allen)	4
BH-12			
BH-13			



P.No.			QTY.
B-I	QJB270-3	Bracket Engine (Small)	1



P.No.			QTY.
B-J	QJB270-2	Bracket Engine (Big)	1




ENG

KK-PP2-8627

P.No			QTY
E-01	1E34F.1.2A	screw(air filter)	1
E-02	1E34F-3E.13-1	Air cleaner Outside Cover	1
E-03	1E34F-3E.13-3	Air cleaner sponge	1
E-04	1E34F-3E.13-4	Baffle (Big)	1
E-05	GB/T70.1	Screw M5x60 (Allen)	2
E-06	GB/T70.1	Screw M5x12 (Allen)	2
E-07	1E34F-3E.13-2	Baffle (small)	1
E-08	1E34F-3E.13.1	Air cleaner Inside Cover	1
E-09	1E36F-3E.1	Carburetor	1
E-10	1E36F-3E-2	Gasket (Carburetor)	1
E-11	GB/T70.1	Screw M5x25 (Allen)	4
E-12	1E40F-3E-9	Pipe (Breather)	1
E-13	1E34FL-3E.11	Insulator	1
E-14	1E34F-3E-1	Gasket (Insulator)	2
E-15	1E34F-3E.3	Reed Valve	1
E-16	GB70.1+GB93+GB97	Screw M5x14 (ALLEN)	1
E-17	1E33F-4	Gasket (Guide Cover)	1
E-18	1E34F-3E.8	Guide Cover Assy	1
E-19	GB/T70.1	Screw M5x18 (Allen)	4
E-20	1E34F-3E.4-1	Cylinder	1
E-21	L 8RTC	Spark Plug	1
E-22	1E34F-3E-3	Gasket (Cylinder)	1
E-23	1E34F.6-5	Piston Ring	2
E-24	1E34F-3E.7-1	Piston	1
E-25	1E34F-3E-8	Gasket (Muffler)	1
E-26	1E34F-3E.5	Muffler	1

E-27	GB70.1+GB93+GB97	Screw M5x65 (Allen)	2
E-28	GB70.1+GB93+GB97	Screw M4x20 (Allen)	3
E-29	1E36F.1A	Starter Assy	1
E-30	1E36F.1.2A	Start Reel	1
E-31	1E34F-3E.11-1	Crank Case (small)	1
E-32	1E31F.4-3	Piston Pin Circlip	2
E-33	1E31F.4-2	Piston Pin	1
E-34	1E31F.4.1	Neddle Bearing (Piston Pin)	1
E-35	GB/T119.2	Pin 4 H8x10 Crankcase)	2
E-36	1E34F-3E.7.1	Crank Shaft Assy	1
E-37	1E34F-3E-6	Clap Board	1
E-38	GB 70.1+GB93+GB97	Screw M5x12 (Allen)	1
E-39	GB/T 276	Ball Bearing 6001/P6	2
E-40	1E34F-3E.11-3	Gasket Crank Case	1
E-41	1E34F-3E.11-2	Crank Case (Big)	1
E-42	GB/T119.2	Pin 4 H8x10 (Fan Copver)	2
E-43	GB/T9074.4	Screw M4x20 (Allen)	3
E-44	1E36F-3E.11	Oil Seal (Crank Shaft)	2
E-45	HA28.2.1.2	Fly Wheel	1
E-46	GB/T6170	Nut M8 (Flanged)	1
E-47	HA28.2.1.1	Ignition Coil	1
E-48	GB 70.1+GB93+GB97	Screw M5x20 (Allen)	2
E-49	1E34F-3E-4	Fan cover	1
E-50	GB 70.1+GB93+GB97	Screw M5x18 (Allen)	4
E-51	1E34F-11	Washer-B	2
E-52	1E34F.10	Clutch shoe assy	1
E-53	1E34F-13	Washer -A	2
E-54	1E34F-12	Clutch bolt	2
E-55	P40.12.2-3A	Petrol filter	1
E-56	EB-415.4.2-2	Fuel pipe grommet	1
E-57	CG420.1.3.2-2	Fuel Pipe (Big)	1
E-58	EB415.4.2-4	Fuel Pipe (Small)	1
E-59	1E34F-3E.10-1	Fuel Tank	1



E-60	GB 70.1+GB93+GB97	Screw M5x16 (Allen)	2
E-61	1E34F-3E-7	N/A	1
E-62	1E32FL.6.2-1	Fuel Tank lid assy	1
E-63	CG420.1.3.1-2	Gasket (Fuel Tank lid)	1
E-64	EB-415.4.1.1-1	BUY # 62	1
E-65	1E32FL.6.2-2		1
E-66	1E32FL.6.2-3		1
E-67	HB33.2.2.1		1
E-68		Starter Cover	1
E-69		Recoil Spring	1
E-70		Rope Reel	1
E-71		Ratchet Spring	1
E-72		Ratchet Starter	1
E-73		Screw -Ratchet	1
E-74		Starter Rope	1
E-75		Starter Handle	1