
## FB-CSE-2418

	FD-C3E-2418
NO	KK-NAME
1	Cable
2	Cable press plate
3	Screw ST 4X12
4	Cable sheath
5	Screw ST 5X16
6	Screw ST 4X14
7	Right handle
8	PC board
	Switch button
9	
10	Self lock spring
11	Capacitance
12	Switch
13	Self lock button
14	Screw ST 3X6
15	Translucentmask
16	Translucentmask fix seat
17	Bar
18	Chain
19	Bar sheath
20	Left handle
21	Switch push rod
22	Brush cover
23	Brush holder
24	Carbon brush
25	Housing
26	Handle fixed plate
27	Screw ST 5x16
28	Screw 4X10 Star
29	Middle cover
30	Screw ST 5x35
31	Screw ST 5x16
32	Right handle insert part
33	Tension spring
34	Sprocket
35	E shield ring
36	
	End cap
37	Locating sleeve
38	Nut-M8 Flanged
39	N/A
40	N/A
41	Tension Block
42	Tension screw
43	Seal ring (Right handle insert part)
44	Seal ring (End cap)
45	Bolt Bar



46	Rubber(Bolt Bar)
47	Screw ST 5x35
48	Dental plate
49	Screw ST 5x16
50	Screw ST 4x14
51	Stator
52	Screw ST 4x60
53	Wind shield plate
54	Bearing
55	Armature
56	Nut M-8 Nylon
57	Bearing-608 RS
58	Big Gear
59	Shaft Sleeve
60	Stopping Torsion Spring
61	output shaft
62	Bearing-6000 RS
63	brake shaft
64	brake spring
65	washer
66	Screw 3x6 Star
67	Gear Half Cover
68	connection rod
69	brake rod press plate
70	gear insert part
71	Screw 4x8 (CSK)
72	Screw ST 4x16
73	fix board
74	brake spring plate
75	Screw ST 3X10 (SPL)
76	Screw ST
77	Oil Pump Fix Board
78	Nut-M8 Flanged
79	Gear Wheel-Rotor
80	Bearing-6000 RS
81	connect wire (1)
82	connect wire (2)
83	connect wire (3)
84	Spring(Switch Push rod)
85	connect wire (4)
86	Screw ST 5x30
87	Front Handle
88	Transmission Housing
89	O ring
90	Screw ST 4X16
91	oil output mouth
92	switch
93	oil pipe(From Tank)

94	oil tank connect head
95	oil tank connection plug
96	sponge(connect head)
97	Airation Jet
98	Buy # 101
99	Buy # 101
100	Buy # 101
101	oil pump Assy
102	Screw ST 3X12
103	oil pipe
104	Front Damper
105	Pin Front Damper
106	oil tank
107	Buy # 110
108	Buy # 110
109	oil tank cover ring
110	oil tank cover Assy