



Part.No	Part Name 7640 Engine
1	Gasket-Insulator
2	Insulator
3	Gasket-Carburetor
4	Carburetor
5	Choker Handle
6	Air Cleaner Inside Cover
7	Choker
8	Air Filter Sponge
9	Air Cleaner outside cover
10	Screw-Air Filter
11	Gasket -Starter
12	Start Claw
13	Claw Spring
14	Start Reel
15	E-Ring 4
16	Oil Seal Small-12x22x7
17	Crank Case Small
18	Gasket-Crank Case
19	Bearing 6202
20	Crank Shaft Assy
21	Key3x5x13-CrankShaft
22	Needle Bearing -Piston Pin
23	Pin B5x12-Crank Case
24	Crank Case-Big
25	Pin B4x10-Fan Cover
26	Oil Seal Big-15x30x7
27	Screw M5x30 -Allen
28	Fly Wheel
29	Nut M8 -Flanged Hex
30	Ignition Coil
31	Cord Comp-Wire
32	Screw M5x20 - Hex
33	Washer B-Clutch
34	Spring-Clutch
35	Clutch Shoe Assy
36	Washer A-Clutch
37	Clutch Bolt
38	Fan Cover
39	Screw M5x25 -Hex
40	Screw M5x12 -Star
41	CirClip -Piston Pin
42	Piston
43	Piston Pin
44	Piston Ring
45	Gasket-Cylinder
46	Cylinder
47	Screw M5x20 -Allen
48	Guide Cover -Assy
49	Screw M5x50- Star



50	Gasket-Guide Cover
51	Screw M5x20-Star
52	Spark Plug
53	Spring-Spark Plug
54	Cap-Spark Plug
55	Gasket –Muffler
56	Muffler
57	Screw- M6x55 Allen
58	Nut M6 -Flanged Hex
59	Clip Board
60	Washer 8-Plain
61	Washer 8-Spring
62	Starter-Assy
63	Screw 4.2x12-Choker
64	Petrol Filter
65	Fuel Pipe-Long
66	Fuel pipe Grommet
67	Fuel pipe-Short
68	Screw M5x16-Star
69	Fuel Tank
70	Buy #76 Fuel Tank Lid Comp
71	Gasket-Fuel Tank Lid
72	Buy #76 Fuel Tank Lid Comp
73	
74	
75	
76	Fuel Tank Lid Comp
77	Cushion -Fuel tank
78	Cushion-Stand
79	Stand -Fuel Tank
80	Screw M 5x16-Star
81	Screw-Ratchet
82	Ratchet-Starter
83	Ratchet -Spring
84	Rope Reel
85	Recoil Spring
86	Starter Cover
87	Starter Rope
88	Starter Handle

Part.No	Part Name 7640 Body
1	Gear Case Assy
2	Stop Ring 28-Inner
3	Stop Ring 12-Outer
4	Bearing 6001 2RS
5	Pinion
6	Steel Plate Cap-Pinion
7	Screw M5x12 –Hex

8	Gear Case
9	Grease Bolt M8x12 –Hex
10	Blade Cover-Plastic
11	Bearing6000
12	Gear
13	Gear Shaft
14	Bearing 6202 -2RZ
15	Stop Ring 35-Inner
16	Holder A
17	Holder B
18	Cover-Metal
19	Washer 8-Star
20	Bolt M8x12 Left thread
21	Screw M5x12 –Star
22	Washer 6-Spring
23	Screw M6x20 -Allen
24	Bearing 6001
25	N/A
26	Rubber Bush-Outer Pipe
27	Oil bearing-Outer Pipe
28	Drive Shaft
29	Outer Pipe-With Bushes
30	Clutch Comp-Assy
31	Clamp A
32	Washer 5-Plain
33	Washer 5-Spring
34	Screw M5x20 -Allen
35	Screw M5x10 -Allen
36	Rubber Cover A
37	Rubber Cover B
38	Linker
39	Stop Ring 15-Outer
40	Bearing 6202-2Rz
41	Stop Ring 35-Inner
42	Clutch Drum
43	Screw M6x20 -Allen
44	Clamp B
45	Wire Clamp
46	Holder Assy
47	Screw M5x20 (STAR)
48	N/A
49	Nut 5
50	Harness Assy
51	Lever Assy
52	Screw M5x30-Allen
53	Washer 5-Plain
54	Buy #51 Lever Assy
55	
56	
57	



58	
59	Box Up-Lever Assy
60	Screw M5x30 star
61	Switch On/ Off
62	Wire Sleeve
63	Throttle Cable
64	N/A
65	Box Down-lever Assy
66	N/A
67	Right Handle
68	Screw M5x16 -Allen
69	Cap Up-Handle
70	Bracket-Handle
71	left handle
72	Handle Rubber Cover
73	Screw M6x20 -Allen
74	Cap Lower-Handle
75	N/A
76	Screw M6x20 -Allen
77	Safety Guard Bracket-Small/Big
78	Safety Guard -Small/Big
79	Blade
80	Tap And Go Stud

	NEW GEAR BOX
	Gear shaft
	Holder -A
	Holder -B
	Nut left Thread
	Sleeve
	Oil Seal 20x35x7
	Cover-Metal