

Part List PWIN-165

S.No	Part Name	
1	Left motor cover	
2	Frame oil seal	
3	Bearing -6302 -2RS	
4	Bearing housing	
5	O-ring 81.5X1.5	
6	Bearing	
7	Bolt 8X20 (ALLEN)	
8	Pump body	
9	In/Out valve cap	
10	O-ring 13X1.9	
11	Valve, Water Inlet/Outlet	
12	O-Ring 16X1.9	
13	Water outlet joint	
14	O-Ring 22X2.4	
	Valve core Assy	
20	Filter	
21	O-Ring 18X2.4	
22	Piston	
23	Joint water inlet	
24	Spring	
25	Handspike	
26	O-Ring 16X2.4	
27	O-Ring	
28	core load release valve	
29	Pump Head	
30	Screw Internal hexagonal	
	Pressure switch Assy	
40	V-ring	
41	O-ring 12X1.8	
42	Interspace ringer	
43	O-ring	
44	Interspace separating ringer	
45	Reinforced seal	
46	Plunger & spring	
47	Plunger clip	
48	motor	
49	Orientation ring	N/A
50	Self-acting screw	
51	Right motor cover	
52	Screw	
53	Capacitor	
54	Connection box	
55	Self-acting screw	
56	Switch	
57	Switch cover	
58	Grounding screw	



