

Part No.	Part Name
1	Nozzle
2	Connector (Nozzle)
3	O-ring (nozzle)
4	Connector (Lance)
5	Cap upper (Lance)
6	Lance
7	Cap Lower (Lance)
8	Pressure Screw/switch assy
9	O-ring Trigger Handle
10	Trigger Handle
11	Cap (Delivery Tube + Trigger)
12	Delivery Hose /Tube
13	Cap (Delivery Tube)
14	Joint (Outlet)
15	O-ring (Outlet)
16	Outlet Tube
17	Filter (outlet tube)
18	Pump Handle
19	Cover-Pump Handle
20	Cap-Pressure Chamber
21	Lid (Cone)
22	O-Ring (Medium)
23	O-Ring (Large)
24	Pressure Chamber
25	Ring (Belt)
26	Buckle (Belt)
27	Belt
28	O-Ring Housing (Pressure Chamber)
29	O-Ring Bottom (Pressure Chamber)
30	Oil Seal (Pressure Chamber)
31	Tank
32	Rod-Safety Valve
33	O-Ring (Safety Valve)
34	Spring (Safety Valve)
35	Cap (Safety Valve)
36	O-Ring (Safety Valve Lock)
37	Lock - Safety Valve

