

## **Warranty Certificate**

(KISANKRAFT COPY)

**Incidental / Consequential Loss:** KisanKraft Limited or its manufacturers will not be liable for general damages, including bodily injuries, or for incidental or consequential damages including, but not limited to, loss of use, loss of profits, loss of production, expense of substitute equipment or other commercial loss or damage.

**Limitation of Liability:** This limited warranty is in lieu of all other express warranties, obligations, or liabilities. Any implied warranties, obligations or liabilities, including, but not limited to, any implied warranty of merchantability shall be limited in duration to the applicable warranty period. Any action for breach of any warranties hereunder, including, but not limited to, any implied warranty of merchantability must be brought within the applicable warranty period.

**Modifications of Warranty:** No agent, representative, dealer, or employee of KisanKraft Limited or any of its manufacturers has the authority to increase or alter the obligations of this warranty.

**Assignment / Transfer of warranty:** The warranty cannot be assigned and shall not transfer if the product is resold by the first buyer. The above warranties are extended to the first end user (original purchaser), and no warranty is made, nor authorized to be made assignable on resale by the first end user.

What you must do to obtain limited warranty service: To obtain performance of any obligation under this warranty for failure during the applicable warranty period, you must deliver the defective product, to the nearest Authorized Dealer, along with proof-of-purchase (invoice/receipt). KisanKraft Limited, its manufacturers and its dealers reserve the right to inspect the claimed defective part(s) to determine if the malfunction is the result of a defect covered by this warranty. Please note that the decision of KisanKraft Limited with respect to any warranty claim is final.

**After-sales Service (Including Warranty):** KisanKraft Limited does not sell directly to consumers. All sales or supplies are made through Authorized Dealers. It is the responsibility of the Authorized Dealer to provide all after-sales service to consumers. Any warranty claim should be raised by dealer to KisanKraft Limited as per warranty policy.

**Jurisdiction:** All disputes are subject to Bangalore court's jurisdiction.

#### Notes:

- > This purchase is not contingent upon a product demonstration. The purchaser shall satisfy himself with the product, including any product demonstration or verification of any function, before buying. KisanKraft Limited or its authorized dealers, including online sellers, shall not be liable to give any on-site demonstration after purchase of any of the product.
- > Any product once used will not be taken back by KisanKraft Limited.
- Warranty and After Sale Services (including but not limited to installation, Demonstration, Repair, Routine Maintenance etc.), should be done through the Authorized Dealer selling this product.
- > Dealers should have their own technician to provide After Sales Services to their Customers. KisanKraft Limited provides free training to Authorized Dealer's technicians at KisanKraft Limited's head office, on request from Authorized Dealer.

This warranty is null & void, if you fail to register the warranty with KisanKraft by sending the KisanKraft Copy with dealer's stamp. KisanKraft Limited

(\$): www.kisankraft.com

**2**: +91.80, 6835 7800



## **Warranty Certificate**

(DEALER COPY)

Product	Centrifugal Water Pump for Agriculture	KisanKraft Invoice Date	
Brand	KisanKraft	KisanKraft Invoice No.	
Model	□ KK-WPE-800C □ KK-WPE-1100C □ KK-WPE-1500C		
WARRANTY PERIOD	6 MONTHS		IED PERIOD FROM THE DATE DELIVERY WHICHEVER IS
Dealer's Invoice Date		Dealer's Invoice No.	
Buyer's Info (Name, Address, Phone, etc.):		Dealer's Stamp (Address, Phone, TIN, etc.):	
Buyer's Sign		Dealer's Sign	

### **Warranty Policy**

**What is covered:** KisanKraft Limited and its manufacturers warrant this product to be free from defects in material or workmanship. All parts defective in material and workmanship are covered.

This warranty will only cover defects arising under normal usage.

This warranty is limited to repair or replacement by KisanKraft Limited or its manufacturers of such parts as appear to KisanKraft or its manufacturers, upon inspection, to be defective in material and/or workmanship. KisanKraft or its manufacturers make no warranty with respect to items not manufactured or sold by them. No onsite warranty is provided by KisanKraft Limited or its manufacturers. Defective items must be brought/sent to our Authorized Dealer or KisanKraft Limited's office for service.

What is not covered: The warranty shall become null and void and neither KisanKraft Limited nor any of its manufacturers, nor its authorized dealers assumes any responsibility, if the failure was caused by the following:

(1) Operation of product with incorrect fuel or lubricants, (2) Incorrect usage of machine or misuse, (3) Lack of maintenance, (4) Negligence, (5) Accident or physical damage, (6) Repairs made by unauthorized parties and/or with unauthorized parts, (7) Improper set up, adjustments, tampering or altered products (8) Any modification to the product what-so-ever.

**Important:** (1) Normal maintenance and adjustments to the product is the responsibility of the customer. (2) Normal wear and tear are not covered under warranty. (3) Rubber/plastic parts and consumables such as blades, clutch and clutch-bell, sparkplugs, nylon line, air-filters, fuel-filters, oil seals and gaskets etc. are not covered under the warranty. (4) Electrical Motor, Electrical Parts, Battery Etc. are not covered under the warranty.

www.kisankraft.com

info@kisankraft.com

## KisanKraft<sup>®</sup>

## **Warranty Certificate**

(DEALER COPY)

**Incidental / Consequential Loss:** KisanKraft Limited or its manufacturers will not be liable for general damages, including bodily injuries, or for incidental or consequential damages including, but not limited to, loss of use, loss of profits, loss of production, expense of substitute equipment or other commercial loss or damage.

**Limitation of Liability:** This limited warranty is in lieu of all other express warranties, obligations, or liabilities. Any implied warranties, obligations or liabilities, including, but not limited to, any implied warranty of merchantability shall be limited in duration to the applicable warranty period. Any action for breach of any warranties hereunder, including, but not limited to, any implied warranty of merchantability must be brought within the applicable warranty period.

**Modifications of Warranty:** No agent, representative, dealer, or employee of KisanKraft Limited or any of its manufacturers has the authority to increase or alter the obligations of this warranty.

**Assignment / Transfer of warranty:** The warranty cannot be assigned and shall not transfer if the product is resold by the first buyer. The above warranties are extended to the first end user (original purchaser), and no warranty is made, nor authorized to be made assignable on resale by the first end user.

What you must do to obtain limited warranty service: To obtain performance of any obligation under this warranty for failure during the applicable warranty period, you must deliver the defective product, to the nearest Authorized Dealer, along with proof-of-purchase (invoice/receipt). KisanKraft Limited, its manufacturers and its dealers reserve the right to inspect the claimed defective part(s) to determine if the malfunction is the result of a defect covered by this warranty. Please note that the decision of KisanKraft Limited with respect to any warranty claim is final.

**After-sales Service (Including Warranty):** KisanKraft Limited does not sell directly to consumers. All sales or supplies are made through Authorized Dealers. It is the responsibility of the Authorized Dealer to provide all after-sales service to consumers. Any warranty claim should be raised by dealer to KisanKraft Limited as per warranty policy.

Jurisdiction: All disputes are subject to Bangalore court's jurisdiction.

#### Notes:

- This purchase is not contingent upon a product demonstration. The purchaser shall satisfy himself with the product, including any product demonstration or verification of any function, before buying. KisanKraft Limited or its authorized dealers, including online sellers, shall not be liable to give any on-site demonstration after purchase of any of the product.
- > Any product once used will not be taken back by KisanKraft Limited.
- Warranty and After Sale Services (including but not limited to installation, Demonstration, Repair, Routine Maintenance etc.), should be done through the Authorized Dealer selling this product.
- ➤ Dealers should have their own technician to provide After Sales Services to their Customers. KisanKraft Limited provides free training to Authorized Dealer's technicians at KisanKraft Limited's head office, on request from Authorized Dealer.

info@kisankraft.com



## **Warranty Certificate**

(KISANKRAFT COPY)

Product	Centrifugal Water Pump for Agriculture	KisanKraft Invoice Date	
Brand	KisanKraft	KisanKraft Invoice No.	
Model	☐ KK-WPE-800C ☐ KK-WPE-1100C ☐ KK-WPE-1500C		
WARRANTY PERIOD	6 MONTHS	FOR THE SPECIFIED PERIOD FROM THE DATE OF SALE OR DELIVERY WHICHEVER IS EARLIER.	
Dealer's Invoice Date		Dealer's Invoice No.	
Buyer's Info (Name, Address, Phone, etc.):		Dealer's Stamp (Address, Phone, TIN, etc.):	
Buyer's Sign		Dealer's Sign	

## **Warranty Policy**

**What is covered:** KisanKraft Limited and its manufacturers warrant this product to be free from defects in material or workmanship. All parts defective in material and workmanship are covered.

This warranty will only cover defects arising under normal usage.

This warranty is limited to repair or replacement by KisanKraft Limited or its manufacturers of such parts as appear to KisanKraft or its manufacturers, upon inspection, to be defective in material and/or workmanship. KisanKraft or its manufacturers make no warranty with respect to items not manufactured or sold by them. No onsite warranty is provided by KisanKraft Limited or its manufacturers. Defective items must be brought/sent to our Authorized Dealer or KisanKraft Limited's office for service.

**What is not covered:** The *warranty shall become null and void* and neither KisanKraft Limited nor any of its manufacturers, nor its authorized dealers assumes any responsibility, if the failure was caused by the following:

(1) Operation of product with incorrect fuel or lubricants, (2) Incorrect usage of machine or misuse, (3) Lack of maintenance, (4) Negligence, (5) Accident or physical damage, (6) Repairs made by unauthorized parties and/or with unauthorized parts, (7) Improper set up, adjustments, tampering or altered products (8) Any modification to the product what-so-ever.

**Important:** (1) Normal maintenance and adjustments to the product is the responsibility of the customer. (2) Normal wear and tear are not covered under warranty. (3) Rubber/plastic parts and consumables such as blades, clutch and clutch-bell, sparkplugs, nylon line, air-filters, fuel-filters, oil seals and gaskets etc. are not covered under the warranty. (4) Electrical Motor, Electrical Parts, Battery Etc. are not covered under the warranty.

This warranty is null & void, if you fail to register the warranty with KisanKraft by sending the KisanKraft Copy with dealer's stamp. KisanKraft Limited

(\$): www.kisankraft.com

**2**: +91.80, 6835 7800

www.kisankraft.com





## Wide Range of Products for Every Need



For more information give MISSED CALL: 07676065555



Many of our products have BIS: ISI certification.





**Centrifugal Water Pump for** Agriculture KK-WPE-800C,1100C, 1500C

## **User Manual**







KK-WPE-800C

KK-WPE-1100C

KK-WPE-1500C

## KisanKraft Limited

Warehouse: 818 3B1 to 818 3B18, Podalakur - Sangam Road, Prabagiripatnam, Podalakur, Nellore - 524345, Andhra Pradesh, INDIA

Head Office: Sri Huchhanna Tower, #4,1st Main,7-A Cross, Maruthi Layout, Dasarahalli, HAF Post, Hebbal, Bangalore 560024, Karnataka, INDIA

◆ Bangalore (HO) ◆ Ahmedabad ◆ Bhopal ◆ Bhubaneswar ◆ Coimbatore ◆ Guwahati ◆ Hubli ◆ Hyderabad ◆ Jaipur ◆ Karnal ♦ Kolkata ♦ Lucknow ♦ Nellore ♦ Pune ♦ Raipur







YouTube

Disclaimer: Pictures used in this manual are only for illustration purpose.



## **CONTENTS**

Before Getting Started	7
Safety Instructions	8
Installation	10
Cleaning And Maintenance	12
Technical Specifications	13
Part Diagram	15



## PRODUCT RANGE

KisanKraft has a large range of products to serve the farmers. A list of our products is given below:

## **Brush Cutters and Accessories**

Brush Cutter/Power Weeder Backpack Brush Cutter Tea Pruner Pole pruner with Engine

Pole pruner with Engine Reaper Attachment Blades-Circular Blades (2 &3 points) Baffle

Nylon Rope Tap & Go

#### **Chainsaws**

Petrol Chainsaw Electric Chainsaw Chain Sharpening Machine

### **Engines and Water Pumps**

Engine –Diesel-(Horizontal)
Engine –Diesel(Vertical)
Engine-Kerosene
Water Pump with Petrol Engine
Water Pump with Kerosene Engine
Water Pump with Diesel Engine

#### **Hand Tools**

Secateurs
Folding Saw
Garden Rake
Garden Shovel
Hedge Shear
Lopper
Telescopic Hedge Shear
Tree Pruner
Telescopic Steel Pipe & Fruit Picker
Bag

## Sheep Shear Garden Tools

Electric Pressure Washer Hedge Trimmer Lawn Mower (Electric, Petrol & Manual) Leaf Blower

#### **Cultivators and Accessories**

Petrol and Diesel

#### Sprayers and Accessories

Battery Sprayer
Portable Power Sprayer
Trolley Sprayer

Manual Knapsack Sprayer Manual Pressure Sprayer

Rose Cans

Hose Crimping Machine

HTP Sprayer

HTP Delivery Hose

HTP Hose Reel

HTP Stand

HTP Gun / Lance(Brass Rod Knapsack Power Sprayer Mister / Duster / Granule Spreader

HTP Sprayer Set with Diesel Engine

HTP Sprayer Set with Kerosene Engine Fogging Machine

## Milking Machine

Wood Shredder Fodder Ensiling Chaff Cutter Fodder Grinder Chaff Cutter Fodder Mini Chaff Cutter

#### Harvester

Maize Sheller
Maize Sheller + Dehusker
Maize Combine Harvester
Onion Digger Carlotta Italy
Tea Leaf Harvester
Sugarcane Combine Harvester
Sugarcane Leaf Stripper

## Transplanter and Post Hole Digger

Paddy Transplanter (2 & 8 Rows) Transplanter-Vegetable & Tobacco Post Hole Digger(4" to 14"Augers)



#### **Part List**

NO.	NAME
1	Bolt
2	Float switch
3	Cable
4	Handle
5	Capacitor Cover
6	"O" ring
7	Capacitor
8	Rubber Washer
9	Upper cover
10	Motor stator
11	Oil seal
12	Oil chamber cover
13	"O" ring
14	Mechanical seal
15	Connection part
16	Rotor
17	Pump body
18	Impeller
19	Thread bushing
20	Cutter knife
21	Pump cover
22	Knife rest
23	Rubber Washer
24	Outlet Connector



## Centrifugal Water Pump for Agriculture KK-WPE-800C,1100C,1500C

Product	Centrifugal Water Pump for Agriculture	KisanKraft Invoice Date	
Brand	KisanKraft	KisanKraft Invoice No.	
Model	☐ KK-WPE-800C ☐ KK-WPE-1100C ☐ KK-WPE-1500C		
WARRANTY PERIOD	6 MONTHS	FOR THE SPECIFIED PERIOD FROM THE DATE OF SALE OR DELIVERY WHICHEVER IS EARLIER.	
Dealer's Invoice Date		Dealer's Invoice No.	
Buyer's Info (Name, Address, Phone, etc.):		Dealer's Stamp (Address, Phone, TIN, etc.):	
Buyer's Sign		Dealer's Sign	

## **Warranty Policy**

**What is covered:** KisanKraft Limited and its manufacturers warrant this product to be free from defects in material or workmanship. All parts defective in material and workmanship are covered.

This warranty will only cover defects arising under normal usage.

This warranty is limited to repair or replacement by KisanKraft Limited or its manufacturers of such parts as appear to KisanKraft or its manufacturers, upon inspection, to be defective in material and/or workmanship. KisanKraft or its manufacturers make no warranty with respect to items not manufactured or sold by them. No onsite warranty is provided by KisanKraft Limited or its manufacturers. Defective items must be brought/sent to our Authorized Dealer or KisanKraft Limited's office for service.

What is not covered: The warranty shall become null and void and neither KisanKraft Limited nor any of its manufacturers, nor its authorized dealers assume any responsibility, if the failure was caused by the following:

(1) Operation of product with incorrect fuel or lubricants, (2) Incorrect usage of machine or misuse, (3) Lack of maintenance, (4) Negligence, (5) Accident or physical damage, (6) Repairs made by unauthorized parties and/or with unauthorized parts, (7) Improper set up, adjustments, tampering or altered products (8) Any modification to the product what-so-ever.


**Important:** (1) Normal maintenance and adjustments to the product is the responsibility of the customer. (2) Normal wear and tear are not covered under warranty. (3) Rubber/plastic parts and consumables such as blades, clutch and clutch-bell, sparkplugs, nylon line, air-filters, fuel-filters, oil seals and gaskets etc. are not covered under the warranty. (4) Electrical Motor, Electrical Parts, Battery Etc. are not covered under the warranty.



KisanKraft®

**Centrifugal Water Pump for A**ariculture KK-WPE-800C.1100C.1500C

**Part Diagram** 



liable for general damages, including bodily injuries, or for incidental or consequential damages including, but not limited to, loss of use, loss of profits, loss of production, expense of substitute equipment or other commercial loss or damage.

Incidental / Consequential Loss: KisanKraft Limited or its manufacturers will not be

**Limitation of Liability:** This limited warranty is in lieu of all other express warranties, obligations, or liabilities. Any implied warranties, obligations, or liabilities, including, but not limited to, any implied warranty of merchantability shall be limited in duration to the applicable warranty period. Any action for breach of any warranties hereunder, including, but not limited to, any implied warranty of merchantability must be brought within the applicable warranty period.

Modifications of Warranty: No agent, representative, dealer, or employee of KisanKraft Limited or any of its manufacturers has the authority to increase or alter the obligations of this warranty.

Assignment / Transfer of warranty: The warranty cannot be assigned and shall not transfer if the product is resold by the first buyer. The above warranties are extended to the first end user (original purchaser), and no warranty is made, nor authorized to be made assignable on resale by the first end user.

What you must do to obtain limited warranty service: To obtain performance of any obligation under this warranty for failure during the applicable warranty period, you must deliver the defective product, to the nearest Authorized Dealer, along with proof-of-purchase (invoice/receipt). KisanKraft Limited, its manufacturers and its dealers reserve the right to inspect the claimed defective part(s) to determine if the malfunction is the result of a defect covered by this warranty. Please note that the decision of KisanKraft Limited with respect to any warranty claim is final.

After-sales Service (Including Warranty): KisanKraft Limited does not sell directly to consumers. All sales or supplies are made through Authorized Dealers. It is the responsibility of the Authorized Dealer to provide all after-sales service to consumers. Any warranty claim should be raised by dealer to KisanKraft Limited as per warranty policy.

**Jurisdiction:** All disputes are subject to Bangalore court's jurisdiction.

#### Notes:

- > This purchase is not contingent upon a product demonstration. The purchaser shall satisfy himself with the product, including any product demonstration or verification of any function, before buying. KisanKraft Limited or its authorized dealers, including online sellers, shall not be liable to give any on-site demonstration after purchase of any of the product.
- > Any product once used will not be taken back by KisanKraft Limited.
- > Warranty and After Sale Services (including but not limited to installation, Demonstration, Repair, Routine Maintenance etc.), should be done through the Authorized Dealer selling this product.
- > Dealers should have their own technician to provide After Sales Services to their Customers. KisanKraft Limited provides free training to Authorized Dealer's technicians at KisanKraft Limited's head office, on request from Authorized Dealer.

(\$): www.kisankraft.com

**2**: +91.80, 6835 7800

(\$): www.kisankraft.com

**2**: +91.80, 6835 7800

Page 6 of 20 Page 15 of 20





ATTENTION! The sound power pressure may exceed 85 dB(A), in this case individual hearing protection must be worn.

Weighted root means square acceleration according to relevant standard.: < 2.5 m/s<sup>2</sup>

The declared vibration total value has been measured in accordance with a standard test method and may be used for comparing one tool with another that the declared vibration total value may also be used in a preliminary assessment of exposure.

A warning that the vibration emission during actual use of the power tool can differ from the declared total value depending on the ways in which the tool is used and of the need to identify safety measures to protect the operator that are based on an estimation of exposure in the actual conditions of use (taking account of all parts of the operating cycle such as the times when the tool is switched off and when it is running idle in addition to the trigger time).



Centrifugal Water Pump for Agriculture KK-WPE-800C,1100C,1500C

## **Before Getting Started**

Thank you for your purchase and use of our products. In order to avoid accidents or injury, please read this manual carefully before using the machine. After reading, preserve it for further reference. Our company will not be responsible for any personal injury or mechanical failure caused by improper operation of the water pump. This manual describes the basic operation and maintenance instructions of new water pump. The data given in this manual is subject to change without prior notice.

**APPLICATION** This pump is used primarily as cellar pump. When installed in a shaft, the pump provides protection from flooding. It is also used wherever water has to be moved from one place to another, e.g., in the home, agriculture, horticulture, plumbing and many other applications.

The CUT pumps are specifically designed for pumping untreated wastewater from domestic, commercial, or municipal sources. The high discharge pressure enables transfer of wastewater over longer distances. The pump can cut up fiber mixture in water easily for example: glovers, rope, cloth, being not wound and no obstruction, it also can reduce energy consumption and keep downtime costs to a minimum, while maintaining peak performance throughout the system life.



WARNING! Read this manual and general safety instructions carefully before using the appliance, for your own safety. Your power tool should only be passed on together with these instructions.

**GENERAL POWER TOOL SAFETY WARNINGS** Read all safety warnings and all instructions. Failure to follow all warnings and instructions may result in electric shock, fire and/or serious injury. Save all warnings and instructions for future reference. The term "power tool" in the warnings refers to your mains operated (corded) power tool or battery operated (cordless) power tool.

#### Caution

The appliance is not suitable for continuous pump operation (e.g., continuous circulation in a pond) or as a stationary installation (such as a lifting device, fountain pump). Caustic, slightly inflammable and other explosive substances such as petrol, petroleum, diluted nitrogen, greases, oils, salt water and wastewater from toilets as well as sludgy water that has a slower flow capacity than water, should not be transported using the pump. The temperature of the transported fluids should not exceed 35°C.



## **Safety Instructions**



#### Danger of death

Violating these safety instructions may result in death through electrocution

- Check the power cord with mains plug for damage before every use. If the power cord is damaged, please arrange immediately for the exchange by an authorized customer service or a skilled electrician.
- All electrical sockets should be fixed in an area that is protected against floods.
- Unsuitable extension cables can be hazardous. Only use extension cables outdoors which
  have been approved for this purpose and labelled with a sufficient cable cross-section. The
  plug and coupling of the extension cable used must be spray watertight.
- Do not use the mains cable or the cable of the level sensor to transport or fasten the
  appliance.
- To separate the machine from the mains, pull the plug and not the power cord.
- Do not scrape the power cord across sharp edges and ensure that it does not get pressed.
- The voltage indicated on the type of plate must correspond to the voltage of the electrical source
- To avoid risks, all repairs and replacement of spare parts may only be carried out by the authorized customer service personnel.
- Follow the rules for electrical safety of equipment: When pumping out swimming pools, garden ponds and fountains, only using an earth-leakage circuit breaker with a nominal leakage current of max. 30 mA with the immersion pump. Do not operate the pump if there are persons located in the swimming pool or the garden pond.
  - For safety reasons, we recommend that you operate the appliance only via an earth-leakage circuit breaker (max. 30 mA).
  - The electrical connection of the system may only be performed by a qualified electrician. Please follow the respective national regulations!
- This device is not intended for use by persons (including children) with reduced physical, sensory, or mental abilities or lacking experience and/or knowledge, unless they are supervised by a person responsible for their safety or are instructed by these persons on the use of the device. Children should be supervised, to ensure that they do not play with the device
- The submersible motor-driven pump must be protected from frost.
- The pump must be protected from running dry.



## Centrifugal Water Pump for Agriculture KK-WPE-800C,1100C,1500C

#### **Technical Specifications**

	Model	KK-WPE-800C	KK-WPE-1100C	KK-WPE-1500	
	Power	0.8 kW 1.1 hp	1.1 kW 1.5 hp	1.5 kW 2 hp	
	Rpm	2850			
	Туре	Thermal protector for single phase			
_	Poles	Two Pole induction motor			
Aoto	Voltage	220V-240V			
Electric Motor	Frequency	50 Hz  Liquid temperature up to 35 °C Max			
Elect	Temperature (max)				
	Ambient temperature Ambient temperature 40°C			°C	
	Winding	Copper			
	Ampere	7.7A	9.3A	11.6A	
	Insulation	В			
	Max Immersion dept	5m			
du	Cable	8m power cable with plug			
r Pun	Pump body / impeller	Cast iron			
Wate	Max Head: m	14 m	19 m	23 m	
ifugal	Min Head m	3 m			
Centrifugal Water Pump	Pump Delivery Size	2"			
	Max Flow Rate:	300 L/min	350 L/min	380 L/min	

Note: Specifications are subject to change without prior notice.

(\$): www.kisankraft.com

**2**: +91.80, 6835 7800

(\$): www.kisankraft.com

**2**: +91.80, 6835 7800

Page 8 of 20 Page 13 of 20



## **Cleaning And Maintenance**



Attention! Before performing any work on the equipment, pull the power plug.



Never use solvents such as petrol, alcohol, ammonia water, etc. These solvents may damage the plastic parts.

#### Service

The pump is maintenance free. Defects must only be repaired by an authorized service station.

#### Cleaning

- When the pump is often transported in the course of operation, it should be cleaned out with clear water after every use.
- In case of stationary installation, the function of the bating switch should be checked every 3 months.
- All fibrous particles which may have built-up inside the pump housing should be removed with a water jet.
- Every 3 months the shaft ground and as should be cleaned from mud.
- Remove deposits on the floater with clear water.



The pump must not be opened by the user.




Centrifugal Water Pump for Agriculture KK-WPE-800C,1100C,1500C

#### START UP

Please follow the safety instructions before start-up!

Please keep in mind that the label "Nameplate" may not be removed from the pump. If the label is removed, there will be no more warranty for the tightness of the pump.



#### Symbols:

Cyllibols.	
lacktriangleright	Denotes risk of personal injury or damage to the tool.
	Read manual before use.
Hmax	Delivery height max
AND THE PROPERTY OF THE PROPER	Size: Foreign bodies
Q max	Delivery rate max.
Tmax	Immersion depth max.
$\epsilon$	In accordance with essential applicable safety standards of European directives
IPX	Degree of protection IP

(\$): www.kisankraft.com

**2**: +91.80, 6835 7800

(\$): www.kisankraft.com

**2**: +91.80. 6835 7800

Page 12 of 20



#### **ELECTRICAL SAFETY**



Always check that the power supply corresponds to the voltage on the rating plate.

#### DESCRIPTION

- 1. Motor housing
- 2. Water inlet
- 3. Water outlet
- 4. Cable & plug
- 5. Floating switch
- 6. Carrying handle

#### Installation

#### Connecting the outlet pipe

■ Connect the outlet pipe to the outlet opening.

**Please note!** You should never install the pump by suspending it unsupported from its delivery pipe or power cable. The submersible motor pump must be suspended from the specially provided handle or be placed on the bottom of the shaft. To guarantee that the pump works properly, the bottom of the shaft must be kept free of sludge and dirt of all kinds.

If the level of water sinks too far, any sludge in the shaft will dry out quickly and stop the pump from

starting up. Therefore, it is necessary to check the submersible motor pump regularly (by carrying out start-up tests). The floater is adjusted in a way that the pump can immediately be started

**Note!** The pump shaft should have minimum dimensions of 40 x 40 x 50 cm, so that the floating switch can move freely.

## Main's supply

Your new submersible pump is equipped with a shock-proof plug according to regulations. The pump is designed to be connected to a safety socket of 220-240V~ 50Hz.

## **Important Note!**

If the mains cable or plug suffers any damage from external action, repairs to the cable are prohibited.

(\$): www.kisankraft.com

**2**: +91.80, 6835 7800



## Centrifugal Water Pump for Agriculture KK-WPE-800C,1100C,1500C

#### **SETTING TO WORK**

After having read these instructions carefully, you can set your pump to work, reconsidering the following:

- Check if the pump rests on the ground of the shaft.
- Check of pressure cord has been attached properly.
- Make sure that the electrical connection is 220-240V~ 50 Hz.
- Check if socket is in good condition.
- Make sure that water and humidity can never come to the mains supply.
- Avoid pump running dry



Before installing or moving the pump always remove the mains plug from the wall socket

## Switching on and off

- To switch on the pump, insert the mains plug in the wall socket.
- To switch off the pump, remove the mains plug from the wall socket. The pump only operates when the float switch floats. This prevents the pump from running dry during operation

**2**: +91.80, 6835 7800

Page 10 of 20 Page 11 of 20

(\$): www.kisankraft.com